



www.rhinocoffeegear.com

Thank you for purchasing the Rhino Stealth Scale. With normal care and proper treatment, you should be able to get years of use from this scale.

General Maintenance & Care:

- Avoid exposure to extreme heat or cold. Although this is a water resistant scale, we do recommend that contact with moisture is limited, if not avoided. Always allow your scale to acclimate to normal room temperature before use.
- Keep your scale in a clean and dry environment. Dust, dirt, moisture, vibration, air currents and proximity to other electronic equipment may affect the functioning and accuracy of the scale.
- Handle the scale with care. Gently place all items to be weighed on the weigh platform. Although this scale is designed to be quite durable, we do still recommend to avoid rough treatment, as this may permanently damage the internal parts. Always avoid shaking and dropping - This is a precision instrument and should be handled with extreme care.

Specification & Function:

- Capacity: 2000g, Accuracy: 0.1g
- Units: g, oz
- Key function: TIME, TARE, MODE, ON/OFF
- Display: LCD display with backlight
- Auto off: default setting is 180 seconds of inactivity; Auto off can be set to 180/300/600 seconds or disabled manually.
- Power: rechargeable Lithium battery
- Operation Temp: 10 to 30 deg C
- Timer: max 9 minutes and 99 seconds

Weighing Operation:

1. Place the scale on a level surface & press the "ON/OFF" button to turn on the scale or power it off.
2. To choose a weighing unit, wait until the LCD display shows zero, press "MODE" to choose either g or oz to weigh in.
3. Place the item to be weighed on the weigh platform and wait until the reading is stable.
4. When finished weighing, press "ON/OFF" to power the scale off.

Timer Operation:

- To start the timer, press "TIME" button.
- To stop the timer during counting, press "TIME" button.
- To zero the timer, press "TIME" button once again quickly.
- The maximum timer counting is 9' (minutes) 59" (seconds).

Calibration:

1. Press ON/OFF button to turn on the scale, and wait until zero is displayed.
2. Press and hold "MODE" button until display shows "CAL", then release the button. Next press "MODE" button again, you will see the required weight will flash on the display. Place the required weight onto the centre of the weight platform.
3. The LCD display reads "PASS" and will return back to the normal weighing mode. Calibration is now completed.

Auto-Off Setting:

- The default Auto-Off setting is 180 seconds of inactivity.
- To change the Auto-Off time setting or disable this function, please follow these steps:
 1. Turn on the scale, wait until screen shows zero.
 2. With the scale powered off, press and hold "MODE" button (do not release), at the same time, quickly press "ON/OFF" buttons 5~6 times or until "180" is displayed. Now release the buttons. Press "MODE" key to cycle through your choices of "0/180/300/600" seconds. Press "ON/OFF" buttons to confirm new setting. Display will show "PASS" and power off automatically.
 3. Power on the scale, to start weighing and using scale normally again.



If user chooses "0" seconds in previous step, Auto-Off function is now disabled and the scale will not turn off until user powers it off manually. To keep a longer battery life, please turn the scale off by pressing the "ON/OFF" button after each use.

Display Warnings:

- "LO": Low voltage. Please recharge battery.
- "O-Ld" / "EEEE": The Scale is being overloaded. Please remove item quickly to protect the scale.